## TOP CAP Replacement Procedure

Please review the pictures of our different Top Caps and order based on the nomenclature shown on the appropriate drawing.

If a visual match cannot be determined, the agent must review the order to find the pole vendor and then use the above to ID component.

Hardware is included.

## Nomenclature Key:


STCP = Square top cap pole


RTC = Round top cap

Vendor Code - Refer to the original order with pole line to identify the correct vendor

- VAL = Valmont;
- HAP = HAPCO

Example for non-stock: RK1SSS 6G STCP VAL





## Replacement Top Caps for SSS Pole (only available in black)



**RK1SSS (Shaft Base Size) STCP VAL** 

Shape = Square Material = Durable Plastic TC Size for 4" Shaft Size = 4" TC Size for 5" Shaft Size = 5" TC Size for 6" Shaft Size = 6"

## Replacement Top Caps for STS and STSH Pole



RK1STS (Pole Height) (Shaft Base Size) STCP (Finish) VAL RK1STSH (Pole Height) (Shaft Base Size) STCP (Finish) VAL

Shape = Square Material = Metal Top Cap Size Varies by Pole Height/Shaft Base Size


Replacement Top Caps for RSS Pole (only available in black)




**RK1RSS (Shaft Base Size) RTC VAL** 

Shape = Round Material = Durable Plastic TC Size for 4" Shaft Size = 4" TC Size for 4.5" Shaft Size = 4.5" TC Size for 5" Shaft Size = 5" TC Size for 6" Shaft Size = 6"

VALMONT





Note: These images are not to scale and should be used for visual identification only.

DISCLAIMER:

Please be advised, Acuity will not be liable for any loses or damages in connection with these replacement parts. Use of information contained on this documentation is at your own risk. Please do your due diligence to research the proper part(s) to match your existing pole(s). For any further questions and concerns, please contact Tech Support at 1-800-279-8041.