

REG127 WX5

Location Recommendations

- ✓ Mounted outdoors, with a mounting height of \ge 20 feet.
- Centrally located among the outdoor lights to be controlled and < 500 feet to the closest nodes if possible. \checkmark
- \checkmark Distance to closest nodes should not exceed 1000 feet.
- ✓ Located ≥ 12 inches from structures and/or heavy foliage, with a clear line of sight to as many nodes as possible.

Mounting Options

Pole Mounting

Use supplied universal mount, articulating bracket & hardware to attach to pole or pipe (See Figure 1). Diameter of pole or pipe must be between 1 and 3 inches.





Figure 2





Figure 3



Figure 4



Figure 6

Remove pole/pipe bracket coupling from the universal mount as shown in Figure 2: install the articulating arm directly to mounting surface using four 1/4 inch anchor bolts as shown in Figure 3.

Orientation

- Pole/pipe may be vertical or horizontal, as the articulating arm provides universal adjustment.
- \checkmark Gateway MUST be oriented vertically, with the large white antenna pointing up (power connection towards the ground), as shown in Figure 4.

Electrical Supply Connection

- The gateway is supplied with 6 feet of cable and a NEMA twist lock power tap. The tap will connect directly to the fixture's NEMA receptacle and allows for a ROAM node to be installed on the top of the tap. See Figure 5 and 6 for proper installation.
- Acceptable supply voltages include 120V, 208V, 240V or 277V.
- The earth ground lug on the bottom of the unit Figure 7 must be utilized.
- Ensure no wire insulation is captured by terminating screw.
- Enclosure shall be grounded using the ground screw by a licensed electrical contractor in accordance with local/ national code requirements.



Figure 7